

QUICK START GUIDE

Adnaco-S5 PCIe Extension System

1. Download the User's Guide

- Access the latest version at: <http://www.adnaco.com/doc/Adnaco-S5-UG.pdf>
(Link is case-sensitive)
- Additional documentation is available at: <http://www.adnaco.com/doc/>

2. Install the System

- Follow the instructions in Section 5 – System Installation of the User's Guide.

3. Configure Power Control

- Refer to **Section 4 – System Operation**.
- **Important:** Power on the remote extension first, then the host computer.
Incorrect sequencing may require a system reboot.

4. Disable PCIe Power Management (Windows 7/8/10/11)

Navigate to:

Control Panel → Power Options → Change plan settings →

Change advanced power settings → PCI Express → Link State Power Management →

Set to: Disabled

Instructions are also available at: <http://www.adnaco.com/doc/>

5. BIOS Settings

- Overclocking is **not supported**.
- PCIe clock frequency must be set to **Default** or **100 MHz**.

6. Troubleshooting

- Refer to **Section 13 – Troubleshooting** in the User's Guide.