

Quick Start Guide

Adnaco-S5 PCIe Extension System

1. Please download and review the latest User's Guide:

<http://www.adnaco.com/doc/Adnaco-S5-UG.pdf> (link is case sensitive)

This file can also be downloaded from <http://www.adnaco.com/doc/>

2. Follow the installation instructions in Section 5, *System Installation*.

3. Set up the power control mode as described in Section 4, *System Operation*, and follow the Power-On/Off sequence. The remote extension has to be powered on first, followed by powering on the host computer. Failure to do so may require re-booting of the computer.

4. It is recommended to disable PCI Express Power Management. In Windows 7 and 8: Control Panel->Power Options->Change plan settings->Change advanced power settings->PCI Express->Link State Power Management ->Settings: Disable. The instructions for Windows can be downloaded from <http://www.adnaco.com/doc/>

5. Overclocking is not supported. The PCI Express clock frequency must be set to either the default value or 100MHz in the BIOS.

6. If you experience any problems, please review Section 13, *Troubleshooting*.